



NIELSEN

Technical Data Sheet



TERMINEX RTU - L352

Water based, ready to use virucide and disinfectant

Terminex RTU is a combined cleaner, virucide and broad-spectrum bactericide making it an essential for good infection control cleaning routines. It is proven effective against a wide range of bacteria.

Terminex RTU can also be used on potential sources of infection prior to deep cleaning.

ADVANTAGES

Proven effective against Hepatitis B and HIV1

Effective against MRSA

Non bleaching and non caustic formula, ideal for use on soft metals, galvanised and most hard surfaces and fabrics

Non perfumed

Active Ingredient

<1% N-(3-aminopropyl)-N-dodecylpropane-1,3-diamine

Water Balance: >98%

TYPICAL APPLICATIONS

Terminex RTU is developed for the cleaning up of blood spillage, vomit, human waste and other bodily fluids from fabrics and hard surfaces adversely affected by conventional bleach disinfectants.

Fabric Safe – Terminex RTU can be used safely, undiluted, on fabric surfaces without bleaching or degrading the material. This allows Terminex RTU to be used for routine cleaning, fabric surfaces and for treatment of fabric following contamination with sickness, incontinence or other body fluids.

APPLICATION INSTRUCTIONS

Check surface compatibility before full scale use.
DISINFECTION OF BLOOD/BODY FLUIDS: Wear suitable protective clothing and gloves. Spray Terminex undiluted onto the affected area. Allow a 10 minute contact time and then absorb or scrape up excess material. Re-apply Terminex to the affected area and allow a further 10 minutes contact time prior to rinsing. Ideally vacuum away residues with wet extraction equipment. Dispose of any bodily fluids or high risk material as contaminated waste.

GENERAL DISINFECTION: For optimum results, pre-clean surfaces before applying disinfectant. Use undiluted and apply by spray, mop or cloth. Rinse away residues with clean water or by using a mop/disposable cloth after the 10 minute contact time.

MADE IN THE



UNITED
KINGDOM



NIELSEN

Technical Data Sheet

TECHNICAL DATA

APPEARANCE	Clear liquid
COLOUR	Colourless
ODOUR	Mild
SOLUBILITY	Completely soluble in water
PH-VALUE CONC. SOLUTION	~11.00
FLAMMABILITY	Non Flammable liquid
PACK SIZES	5 litre

PRECAUTIONS

Wear protective gloves and avoid contact with skin, eyes and clothing. Avoid spilling.

STORAGE PRECAUTIONS

Store in a tightly closed original container in a dry, cool and well-ventilated place. Store between 4°C – 40°C.

HEALTH AND SAFETY

Health and Safety Data Sheet available separately.
Use biocides safely. Always read the label and product information before use.

The values are typical of normal production and should not be taken as a specification.

RELATED PRODUCTS



BACTERICIDAL APC

Truly universal cleaner, designed to be the most versatile product for use in the automotive sector



BIOCIDAL CLEANER & SANITISER

Hard surface cleaner, sanitiser and disinfectant, ideal for food area use



MEDICAL WIPES

Developed in response to the growing need for a single cleaning and disinfectant wipe that is effective against a wider range of pathogens, including spores



ONE SHOT

Single application odour neutraliser and freshener for air conditioning and ventilation systems



ISO 9001
Quality Management Systems
CERTIFIED
Q 05320

ISO 45001
Occupational Health and Safety Management
CERTIFIED
OHS 536783

